


Technical Data Sheet Residue-less Flux for Area Laser Applications RLFP008

	Value	Method
Viscosity (Pa·s)	13	Rheometer (NETZSCH, Kinexus)
Thixotropic Index	0.43	Rheometer (NETZSCH, Kinexus)
pH (1g, 30mL IPA)	4.25	Titration
Acid Value (mgKOH/g)	23.85	JIS 3197 8.1.4.1.1
Halide Contents (wt%)	Not added	JIS 3197 8.1.4.2.1
Tackiness (gf)	130	JIS Z 3284-3 4.5

Test Conditions

- 【Mask】 Aperture size ϕ 0.3mm t30 μ m
- 【Substrate】 Pad size ϕ 0.3mm ENIG
- 【Component】 SAC305 Solder Ball ϕ 0.3mm
- 【Heating】 Size 50mm x 50mm, Power 2000W, Time 2sec
- 【Device】 Printer (YAMAHA, YCP10), Area Laser (LASERSSEL, LSR 3000)

Test Results




- Achieving low residue with short-time heating by an area laser.

Test Conditions

- 【Mask】 Aperture size ϕ 0.3mm t30 μ m
- 【Substrate】 Pad size ϕ 0.3mm ENIG
- 【Component】 SAC305 Solder Ball ϕ 0.3mm
- 【Heating】 Size 50mm x 50mm, Power 2000W, Time 2sec
- 【Device】 Printer (YAMAHA, YCP10), Area Laser (LASERSSEL, LSR 3000)

Test Results



- Good wettability is achieved by short-time heating using an area laser.

Test Conditions


【Printing】 Speed: 15mm/s, Interval: 10sec

【Environment Conditions】 Temperature 24°C, Humidity 35%


【Device】 Printer (Hitachi, HIGRAD HG-610), Rheometer (NETZSCH, Kinexus)

Test Results

Viscosity



TI



- Stable viscosity and TI over 8 hours of continuous printing.

Test Conditions


【Mask】 Aperture ϕ 6.5mm t200 μ m

【Probe Diameter】 ϕ 5.1mm 【Maintaining Pressure】 50gf

【Pressure Time】 0.2sec 【Permeation Rate】 2.0mm/sec 【Retraction Speed】 10mm/sec

【Device】 Tacking Tester (Malcom, TK-1S)

Test Results



- Tackiness remains above 100 gf for 24 hours.

- ① Do not use this product for other purposes except soldering.
- ② Do not touch this product directly. In case of skin contact, wipe with tissue or cloth with alcohol or appropriate solvent then wash by soap water.
- ③ Do not inhale fume generated from this product. Adequate ventilation is required.
- ④ Recommended storage condition and quality guarantee period are as follows:
Keep refrigerated (0-10℃) : 3 months from manufacturing date.
- ⑤ When it backs to room temperature (24℃), avoid to heat too rapidly.
Keep it at room temperature and wait for 1-2 hours. Do not use it when it is refrigerated.
- ⑥ Chlorinated or fluorinated solvents or other type of solvents will cause degrading of solderability.
Please be careful in cleaning of supplying tools.
- ⑦ Please keep it away from any fire source in working place or store room.